

Installation of TosBlue-X and TosBlue-Y

NOTE: The installation procedure for both products is the same.

If your TV is equipped with an optical output port (SPDIF), then you are recommended to use the enclosed optical cable – and not the 3,5 mm signal cable.

If your TV does not have the optical output, then use the 3,5 mm stereo signal cable instead.

(Only 2 of the 3 included cables should be used).



Optical cable



3,5 mm cable



USB cable

The unit should be located on back of your TV so that the top of the unit is visible from the front.



TosBlue mounted on the back of the TV

- Find a flat surface on the back of your TV and make sure the surface is clean.
- Both ends of the optical cable are protected with plastic caps. Remove the caps.

NOTE:

Do not sharply bend the optical cable as it may be severely damaged, causing weak or no signal to go through.



- Connect one end the optical cable to the unit. (*Middle connector*) Make sure that the cable is well connectedi.e. well pushed into the socket.

NOTE:

If not well connected, no or weak signals may be transmitted and you may experience sound disturbance, or no sound at all!

- Connect the USB cable to the unit. (*Right connector – see picture above*)
- Peel off the white coating (protecting) tape covering the Velcro pad on the unit.
- Fasten the unit on the back of the TV so the top of the unit is visible from the front.
- Connect the other ends of the 2 cables to the corresponding connectors on your TV.

D O N E

NOTE:

If your TV does not have an optical output port you can use the 3,5 mm cable instead. (Left connector – see picture above)